



Ridge Collection

DESIGNED IN 2021

ASSEMBLY NOTES | REV 02



NEED A HAND?

Contact us at service@bludot.com or
844.425.8368 for assistance.

@BLUDOT



We design all our pieces in our Minneapolis studio. Follow
along on Instagram for some sneak peeks into the process.

Step 01

ATTACH CENTER LEG.

With assistance from another individual, carefully place the sofa on a flat, soft surface as shown. Use provided hardware to attach the center leg.


NOTE: This step may be skipped for the lounge chair size.



Step 02

PLACE BACK CUSHION.

Position the back cushion in place to complete assembly. Adjust the adjustable glides at the bottom of the legs to ensure that the sofa is level prior to use.



NOTE

This product is upholstered with Sunbrella® fabrics. Sunbrella fabrics are treated to be water and stain repellent, and do not promote mildew growth. We recommend regular cleaning as mildew can grow on dirt and dust embedded in the fabric.

CLEAN

Vacuum your upholstery regularly, this will help prevent dirt and dust from becoming embedded in the fabric. To remove minor wrinkles, we recommend using an iron on the synthetic setting.

SPILLS

Act quickly with spills. Blot the spill with a clean white cloth or paper towel. Never rub the surface. Apply a solution of mild dish soap and water to the surface containing the spill. Rinse the fabric surface thoroughly to remove any residue, working from seam to seam. Air Dry. Consult a commercial cleaning specialist for removal of stubborn stains.

MOLD AND MILDEW STAINS

Mildew can grow on dirt and dust embedded in the fabric. Before cleaning we recommend moving the furniture piece to a safe work space or covering the surrounding floor. To remove mold or mildew stains we recommend applying a solution of 1 cup bleach and ¼ cup mild dish soap per 1 gallon of water. Allow the solution to set for up to 15 minutes. Clean the entire surface with a soft sponge and rinse thoroughly to remove any residue, working from seam to seam. Air dry completely before using.

AVOID

Avoid placing heavy or sharp objects on the furniture surface for long periods of time; this can cause permanent surface indentations. For snags in the fabric, tuck loose threads into fabric or carefully push to reverse side. Never pull out or cut off loose threads. Do not use a fabric steamer to remove wrinkles, this can damage the fabric.

MAINTAIN

Teak naturally expands and contracts over time, which may result in small cracks in the joint or wood grain. This does not affect the strength and integrity of the frame. Weathering and color variation over time is natural for teak outdoor furniture which may result in graying over time. For best results, we recommend the following care: Wipe spills with a clean dry cloth, cover furniture in the off-season, and store indoors during winter months. Store cushions separately from furniture to help prevent staining.

PROTECT

Our unfinished teak contains natural oils that are inherent to this wood species. When teak is exposed to moisture and rain, its natural oils may come to the surface and resemble water stains. To protect and revive weathered furniture, it is recommended to seal teak furniture. Water based sealants are most effective on bare wood, consult with your local hardware professional to select the sealant best suited for your outdoor furniture.

Sunbrella® is a registered trademark of Glen Raven, Inc.

