


Tether Outdoor Woven Occasional Ottoman



DESIGNED IN 2024

CARE NOTES | REV 00



CLEAN

Clean metal frame with a slightly damp, soft cloth. To remove dirt and fingerprints, use a quality cleaner formulated for metal furniture. Wipe completely dry with a soft cloth.

Clean rope surfaces with a slightly damp, soft cloth with mild soap. Avoid rubbing the rope surface too vigorously as this could cause damage to the rope. Allow rope surface to air dry before use.

MAINTENANCE

We recommend the following care: Wipe spills with a clean dry cloth, cover furniture in the off-season, and store indoors during winter months.

