



# Turn Felt Pad

DESIGNED IN 2013

ASSEMBLY NOTES | REV 00



Remove backing from felt pad and align edges with top cut out area. Make sure adhesive back fully sticks to wood surface.



## CARE

Our felt is 100% German wool felt, a naturally renewable and recyclable material and because of its wool properties, this product is not suitable for washer and dryer cleaning. If soiling should occur, please spot clean with warm soapy water or dry clean.

